

CASTLE WATERPROOFING

PME-995 CEMENTITIOUS WATERPROOFING

English:

1. Break the seal and mix the product until uniform from top to bottom, then transfer to a larger bucket if needed.
2. Add 3 kg of cement and mix for 5–10 minutes until fully incorporated, either by hand or with a power tool, ensuring all cement is thoroughly blended into the mixture.
3. Use all compounded material immediately, preparing only the amount required per coat; coverage is approximately 9 sqm per coat or 3 sqm for 3 coats as the standard process.
4. Allow each coat to dry for 40–60 minutes in direct sunlight or 120 minutes without sunlight, confirming dryness by touch before applying the next coat.
5. After completing three coats, allow the surface to cure for at least 2-3 days before performing flood testing.
6. Note:
 - a. For small cracks, mix the product with cement and apply it like putty to fill the gaps.
 - b. Do not use sharp objects to puncture the membrane after application

Tagalog:

1. Buksan ang selyo at haluin ang produkto mula itaas hanggang ibaba hanggang maging pantay, pagkatapos ay ilipat sa mas malaking timba kung kinakailangan.
2. Magdagdag ng 3 kilo ng semento at haluin nang 5–10 minuto hanggang tuluyang mahalo, gamit ang kamay o gamit ang power tool, siguraduhing lubos na nahahalo ang lahat ng semento sa timpla.
3. Agad gamitin ang lahat ng nahalong materyales at maghanda lamang ng sapat para sa bawat patong; ang coverage ay humigit-kumulang 9 sqm bawat patong o 3 sqm para sa 3 patong bilang pamantayang proseso.
4. Patuyuin ang bawat patong nang 40–60 minuto kung may direktang sikat ng araw o 120 minuto kung nasa loob o walang araw, at tiyaking tuyo sa paghipo bago maglagay ng kasunod na patong.
5. Pagkatapos makumpleto ang tatlong patong, hayaang mag-cure ang ibabaw nang hindi bababa sa 2-3 araw bago magsagawa ng flood testing.
6. Tandaan:
 - a. Para sa maliliit na bitak, haluin ang produkto at semento at ipahid na parang masilya upang mapuno ang mga siwang.
 - b. Huwag gumamit ng matutulis na bagay na maaaring bumutas sa membrane pagkatapos ng aplikasyon.